



# Care & maintenance instructions



**To ensure you maintain your warranty and gain the maximum benefits from your choice of rainwater goods, we recommend the following:**

- Washing of naturally unwashed areas at least every 6 months (painted surface of spouting, fascia & downpipes).
- Removal of debris from gutters every 6 months.
- Removal of any noticeable build-up of salt deposits and/or other contaminants when identified.

## General care:

- Do not water blast the inside of your spouting as this can cause leaking at the joins.
- The best method for washing your spouting is the use of a soft nylon broom, mild detergent & a garden hose.
- Avoid leaning ladders against your spouting as scratches & indentations are difficult to repair.
- When cleaning or treating your roof for moss, mould etc., use caution as some cleaning products are very caustic and can reduce the life of your spouting.
- When considering over-painting, please consult with your Continuous Agent to ensure the correct procedures are undertaken.

**Congratulations on purchasing quality products & services from the Continuous Group**

Our commitment to every customer is to exceed their expectations, whilst making the process simple, efficient and non-intrusive. Should you have any questions regarding aftercare, please do not hesitate to contact your local Continuous Team:

**0800 50 1993**

[www.continuous.co.nz](http://www.continuous.co.nz)

